

Stopwatch Function:

Press A to enter stopwatch mode.

If it's not in the "0" state, press B to stop timing.

Press C back to "0" state.

Press B to start then stop timing.

**Time Display Function:**

Press A to enter time display mode.

Press B to display MONTH, DATE and WEEKDAYS:

Press C to display preset alarm time.

Press B and C simultaneously, it will beep.

Time Adjustment:

In the time display mode, press A three times to enter the time set mode with the digits of second and weekdays blinking. Press B to adjust the digits of second.

Press C to select digits in the following sequence: MIN, HR, DATE, MONTH, and WEEKDAYS.

("A/P" stands for 12-hr. time format; "H" stands for 24-hr-time format)

Press B to adjust.

Press A back to the time display mode after completing the adjustment.

Alarm Setting:

In the time display mode, press A twice with the digits of HR and WEEKDAY blinking simultaneously.

Press C to select the digits of HR or MIN.

Press B to set alarm time.

Press A back to the time display mode after completing the alarm setting.

Hourly-alarm Setting:

In the time display mode, press and hold C first, then press A. If there are Weekdays display, hourly-alarm is armed; if not, it's disarmed.

Changing the battery:

Open the battery cover "D" on the back of the stopwatch by turning it counter-clockwise with a screwdriver or a coin.

Tap the stopwatch - with the back facing downwards - in the other open hand so that the battery falls out.

Replace the battery with a new one of the same type:

DG130-1C Battery 1.5V, V13GA, LR44

Pay attention to the polarity!

After inserting the new battery, press it down slightly with your finger and place the battery cover in the correct position (turn the cover clockwise).



Notes:

Avoid allowing the stopwatch to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.

Avoid exposing the stopwatch to temperature extremes.

Avoid the stopwatch from long-term exposure to direct or strong sunlight.